

FPC连接器对应表			
序号	LCD	GM_LINK A	GM_LINK B
1	VCC	12V	12V
2	VCC	12V	12V
3	DE	NC	NC
4	VSYNC	E15	K9
5	HSYNC	F13	L7
6	LCD_B7	F14	L6
7	LCD_B6	L13	M6
8	LCD_B5	GND	GND
9	LCD_B4	K11	R8
10	LCD_B3	J11	P7
11	GND	K12	P6
12	LCD_G7	J13	N6
13	LCD_G6	GND	GND
14	LCD_G5	K14	R5
15	LCD_G4	K13	P5
16	LCD_G3	L15	R4
17	LCD_G2	L14	P4
18	GND	GND	GND
19	LCD_R7	M15	R3
20	LCD_R6	M14	P3
21	LCD_R5	N15	R2
22	LCD_R4	N14	R1
23	LCD_R3	GND	GND
24	TFT_CLK	P15	P2
25	GND	P14	P1
26	PENIRQ	R15	N2
27	LCD_BL	R14	N1
28	LCD_CTRL	GND	GND
29	TOUCH_MOSI	P13	L3
30	TOUCH_MISO	R13	K7
31	TOUCH_SCK	P12	K4
32	TOUCH_CS	R12	K5
33		GND	GND
34		P11	M2
35		R11	M1
36		N10	L2
37		P10	L1
38		GND	GND
39		P9	K3
40		R9	K2
41		L10	J3
42		R7	H1
43		GND	GND
44		N11	J6
45		L11	J5
46		M10	E1
47		N9	E2
48		NC	NC
49		12V	12V
50		12V	12V

按键/LED引脚对应表			
序号	对应名称	对应引脚	连接芯片
1	ARM_KEY	PG9	ARM
2	ARM_LED R	PI4	ARM
3	ARM_LED G	PI3	ARM
4	ARM_LED B	PH14	ARM
5	FPGA_KEY	B5	FPGA
6	FPGA_LED R	B14	FPGA
7	FPGA_LED G	A15	FPGA
8	FPGA_LED B	B15	FPGA